

MANHOLE FALL PROTECTION

INSTALLATION INSTRUCTIONS

1	Remove manhole lid
2	Remove loose rust and dirt
3	Measure clear opening of casting. Select correct size grille
4	Place grille into casting
5	Using 24mm spanner tighten nut to expand grille until tight
	and secure. Ensure load tabs are seated fully down onto
	casting (soft hammer may be required)
6	Attach 2.5mm anti-theft cable to preferred location
	ie: cast lid or concrete riser
7	Replace manhole lid

NOTE: Anti-theft cable is optional but recommended to deter theft and ensures grille is reinstalled before closing lid

Install should take less than 5 minutes !!

